


## 433RF Wireless Trigger User Guide

This wireless trigger is designed to use with Stoltzen Cronos and Stoltzen Hide projection screens. It wirelessly triggers projection screen when the projector is turned on/off.



DC239



USB Converter Cable

### Specifications:

Battery: CR2430 3V



Input: AC/DC5-12V

Trigger interface: 3.5mm mini port

Frequency: 433.92Mhz +100Khz

Operational distance: 10m

Operational temperature: -10°C-50°C



### Instruction:

#### A. Pairing – Operate within 2m distance from the screen

1. Open the back cover of the RF remote. Press P2 button twice
2. Press pairing button on the 433RF trigger one time, the red light will flash
3. Connect 433RF trigger with the USB converting cable. Plug into the any USB power source, the screen fabric would come down. Unplug it from the USB power source, the screen fabric would retract. Once done, the pairing process is finished.

#### B. Projector connection

1. If trigger port is available on the projector, simply connect the 433RF trigger to it directly.
2. If trigger port is not available on the projector, connect the 433RF trigger to the supplied 3.5mm to USB converter cable. And plug it into the projector's USB port. Ensure the USB port is powered when projector is turned on and vice versa.

